VERGO

www.vergoindustrial.com

Vergo Industrial Pallet Buster



INSTRUCTION MANUAL


Please read all the instructions thoroughly before attempting the installations, this manual should be kept properly for future reference.

Thanks for purchasing **VERGO** pallet buster.

This item is easy-locking with heavy duty powder-coated steel and strong locking pin made to be long-lasting, great for warehouse, loading dock, delivery.

PARTS LIST & STRUCTURE

No	Item	Qty
①	Dual pry head	x1
②	Bottom handle	x1
③	Central handle	x1
④	Top handle	x1
⑤	Rubber grip	x1
⑥	D-pin	x1
⑦	Fasten bolt	x2
⑧	Fasten washer	x2
⑨	Fasten nut	x2



ASSEMBLY INSTRUCTIONS

STEP 1:

Connect dual pry head (①) to bottom handle (②) with D-pin (⑥).

STEP 2:

Connect central handle (③) to bottom handle (②) with one set of fasten bolt, washer and nut each (⑦⑧⑨, x1).

STEP 3:

Connect top handle with rubber grip attached (④⑤) to central handle (③) with one set of fasten bolt, washer and nut each (⑦⑧⑨, x1).

WARRANTY

This warranty applies to pallet buster and not to pallet buster it has been mounted to where damage may occur from the installation process.

This item covers **1 YEAR LIMITED WARRANTY** from the original date of purchase. During the warranty period, we will replace any part which in our opinion is defective. If the item has not been subjected to tampering, vandalism, alteration, accidental damage after installation, roadside hazards, or improper use after delivery. Our obligation does not include the cost of transportation. We are not responsible for damage in transit, and claims for such damage should be presented to the carrier by the customer. This item is no warranted against misuse, use in extreme temperature conditions, exposure to damaging chemicals, or use in a commercial operation.

If you have any questions, please visit our website and contact our customer service.

www.vergoindustrial.com